
Lectures 14, 15, 16: Connections, Protocols, Link and Flow Control, LANs


Brian Carpenter


314 S1T 2008

Transmission Modes (Shay 4.3)

- Parallel (many wires) or Serial (one wire)
- Direction-related







communication can go both ways simultaneously.

COMPSCI 314

both ways, but devices

must alternate sending.


2

Transmission Modes

- Time-related
 - asynchronous: may start/stop at any time



- synchronous: uses a continuous clock



- isochronous: imposes gaps to match transmission rates


Interface Standards (Shay 4.4)

- There are lots of 'standard' interfaces for connecting devices together
- Shay has good descriptions of:
 - EIA-232 (RS-232) <= we only look at this one
 - USB
 - IEEE 1394 (Firewire)
 - X.21


COMPSCI 314 3 COMPSCI 314

RS-232 Serial Interface

Connects DTE (computer) to DCE (modem)



• 25-pin connector, we normally use only 9



COMPSCI 314

5

RS-232 Serial Interface

• Null Modem for connecting two DTEs


Pin#	Function			Pin#	Function
2	Transmit data		•	2	Transmit data
3	Receive data		-	3	Receive data
5	Clear to send		-	5	Clear to send
4	Request to send		•	4	Request to send
6	Data set ready		-	6	Data set ready
8	Data carrier detect		-•	8	Data carrier detect
20	Data terminal ready		•	20	Data terminal ready
7	Electrical ground	•	•	7	Electrical ground
		DTE	DTE		

• Not used here: pin 22 = Ring Indicator, pin 1 = Protective Earth

COMPSCI 314 6


Multiplexing (Shay 4.5)

- Ways of carrying several different connections over a common link
- Frequency-Division (FDM):



Multiplexing (2)

Time-Division (TDM):




- Statistical Multiplexing
 - Much the same as TDM, but doesn't use fixed time allocations (slots)
 - Receiver must be able to identify incoming frames

COMPSCI 314

Multiplexing (3)

Wave-Division (WDM):



Flow Control (Shay 8.1)

- Need for flow control
 - how can we send long messages, e.g. big files?
 - what happens when messages get lost, or are corrupted when they arrive?
 - what if the receiving *host* is busy, i.e. slow to accept incoming data?
 - how will a sender cope with lost (undelivered) messages?
 - will both hosts be able to send/receive at the same time?

COMPSCI 314 10

What is Flow Control?

- Messages are broken into frames
- Flow Control defines
 - "the way frames are sent, tracked and controlled"
 - may be simple or complex
- Many examples of protocols around us, e.g. traffic rules (Road Code), 'phone conversations
- How can we be sure that a protocol is correct?
 - works properly
 - will never suddenly 'freeze'

Signaling (Shay 8.2)

Receiver tells sender when it's ready to receive

COMPSCI 314

buffer overflow • DTE (computer) -DCE (modem) via RS-232 interface ..

• Prevents receiver

My buffers are filling up. please stop sending. data strean I have received your signal Receiver and I will not send anything until I receive another signal.

XXXXXX....XXX

Receiver

COMPSCI 314

11

12

I have room in my buffers

so I will accept data.

X-ON/X-OFF

- Over the DTE-DCE path ..
 - send ASCII X-OFF (0x13, ^S) to stop transmission
 - send X-ON (0x11, ^Q) to start it again
- This is *in-band* signalling, i.e. send signal on same path as data
- How quickly does the transmitter stop sending?
- How can we send 0x11 or 0x13 to the receiver?

COMPSCI 314 13

Stop-and-Wait

- Sender:
 - send frame, wait for ACK or NAK
 - if NAK, send frame again. Repeat unil get ACK
- Receiver:
 - receive frame, check for errors
 - if OK, send ACK. otherwise send NAK
- No way to handle lost (therefore not ACKed) frames

COMPSCI 314

Frame-oriented Control (Shay 8.3)

- Idea is to break large sequences of chars into smaller frames
- Frames are sent from one *user* (higher protocol layer) to another
- Unrestricted protocol
 - simply assume it's always safe to send
 - not really a useable protocol!

COMPSCI 314

Protocol Efficiency: Effective data rate

- Shay derives formulae, we "just work it out"
- Remember, *velocity* = *distance* / *time*
 - in wire or fibre, v is ~2/3 speed of light, i.e. $2x10^8$ m/s
 - Auckland-Hamilton is about 120 km, so a byte takes $(120 \times 10^3)/(2 \times 10^8) = 0.6$ ms to get there
 - If we send a 1500-Byte frame at 10 Mb/s, it will take $(1500 \times 8) / (10 \times 10^6) = 1.2 \text{ ms to transmit}$
 - Assume that ACK is a 64-Byte frame, 0.0512 ms
 - Therefore, to send frame and receive ACK takes roughly $1.2 + 0.05 + 2 \times 0.6 = 2.45 \text{ ms}$
 - Effective bit rate is $(1500 \times 8)/(2.45 \times 10^{-3}) = 4.9 \text{ Mb/s}$
 - → Half the time is wasted waiting for ACKs

COMPSCI 314

14

Side note: a catch in the notation


- Convention:
 - Mb/s for megabits per second
 - MB/s for megabytes per second
- Often leads to confusion, especially with marketing people, journalists, and politicians.
- If there is any chance of confusion, write "megabits" or "megabytes" in full.
- In data communications, we normally discuss megabits. But when considering application throughput, megabytes are more useful.

COMPSCI 314 17

Sliding Window / Go-back-n

- Idea here is to have a maximum of *i* frames on the wire at any time. *i* is the *window size*
- Each frame has a sequence number, sender must hold each frame until it is ACKed
- Sender keeps track of w, sequence number of first (of i frames) in window. When frame w is ACKed, sender can forget it
- Window does not move until earliest frame has been ACKed

Sliding Window (Shay 8.4)



COMPSCI 314 18

Go-back-n

Shay develops a frame format for two-way communication

ation Number ACK TypeData	Destination N	Source	ation Number
---------------------------	---------------	--------	--------------

- Data frame in one direction can carry an ACK for the other direction, i.e. a piggy-backed ACK
- To handle lost frames, he has an ACK timer at the receiver ..
- and a frame timer at the transmitter

COMPSCI 314 19 COMPSCI 314 20

Sequence Numbers


- Sequence Numbers fit in a K-bit field;
 there can be at most 2^k frames in the window
- K should be big enough to handle the maximum window size we expect to use
- They are unsigned numbers, and can wrap, i.e. count through 2^K-2, 2^K-1, 0, 1, 2, ...
 You can think of the sequence numbers as being arranged in a circle
- What happens if a host crashes and restarts?
- Some protocols used *lollipop sequence numbering* to handle restarts! (see Wikipedia)

COMPSCI 314 21

Selective Repeat (2)

- Any frame can be ACKed, specifying it's sequence number
- Frames arriving out of sequence are buffered until earlier frames have been ACKed
- When a NAK is received, only the NAKed frame is resent (Go-Back-n resent the whole window!)
- If a frame timer expires (no ACK or NAK), only the timed-out frame is resent
- Piggy-backed ACK acknowledges the last frame delivered to the user, so the sender knows that all frames up to that one have been safely received

Selective Repeat (Shay 8.5)




COMPSCI 314 22

Efficiency of Sliding Window Protocols (8.6)

- For a particular window size, message size, transmission speed and link distance, we can "just work it out," as we did for stop-and-wait
- We assume no lost or damaged packets!
- Two cases
 - we get our first message ACKed before we've sent a whole window. That allows us to keep sending at full link speed
 - we have to wait for an ACK after sending a window, then we can send another window. Shay has a diagram illustrating this ..

COMPSCI 314 23 COMPSCI 314

Sending whole window and waiting



Numerical examples

- Sending 100x 1500B frames in 20-frame windows, Auckland-Hamilton on a 10 Mb/s link
 - as for Stop-and-Wait: 1.2ms to send frame, 1.2ms round-trip time. Any window > 2 frames can run at full speed, 10 Mb/s
- As above, but with 64B frames
 - send time is $(64 \times 8)/(10 \times 10^6) = 0.0512 \text{ ms}$
 - time to send 20 frames = 20 x 0.0512 = 1.024 ms
 - first ACK returns after 1.2+2*0.0512 = 1.3024 ms
 - effective bit rate is (20 * 64 * 8)/1.3024 = 7.862 Mb/s
 - note the effect of using a small frame size!

COMPSCI 314 26

Bandwith-Delay Product (BDP)

- BDP for a link = data rate x link delay*
- Auckland-Hamilton at 10 Mb/s: $BDP = 10 \text{ Mb/s } \times 0.6 \text{ ms} = 6000 \text{ bits}$ = 750 B
- This is the maximum number of bits we can have 'on the wire'
- Need to have buffers at least double this so that transport protocol can keep the link busy
 - fill the wire once, and then again before first ACK returns
- Bigger frames sizes help to keep the link busy less protocol overhead

COMPSCI 314


*one-way delay, not round-trip time

Protocol Correctness (Shay 8.7)

- Shay discusses two ways to describe systems:
 - Finite State Machines
 - Petri nets
- Finite State Machine models a system as being in one of a finite set of states
- State Transition Diagrams (STDs) are graphs, each vertex represents a state, and each edge a transition between states
- Petri nets are more detailed, we won't discuss them further

COMPSCI 314

State Transition Diagrams



- Look for problems on graph
 - No edges pointing to S₁
 - $-S_{\epsilon} S_{\epsilon}$ is an infinite loop
- This kind of analysis helps find flaws

process sending information

- it doesn't prove correctness!

COMPSCI 314

process receiving information

29


Layers are an abstraction, they provide a

Protocol Layers, the OSI Model (reminder)

- simple view of what happens in a communication system
- Layer *n*
 - provides services to layer n+1
 - uses services from layer *n-1*
- Generally we implement systems this way, but sometimes we may find it useful to peek between layers, or 'break layer purity'

COMPSCI 314 30

OSI Model



physical transmission of data stream

- OSI has 7 layers, TCP/IP collapses 5-7 into 5
- So far, we've mainly discussed layer 1

Introduction to LANs (Shay 9.1)

- LANs connect many hosts (devices) together
- Link medium may be copper (coax or UTP), fibre or wireless
- Topology may be
 - bus: hosts share the medium by taking turns
 - ring: access is controlled by pasing a token
- Ethernet today's most common LAN physical layer – uses a bus topology
- Point-to-point link is a LAN with only two hosts

COMPSCI 314 31 COMPSCI 314


LAN Layers

- Layer 1 is the Physical layer. On this layer, you've already looked at signaling and modulation methods
- Layer 2, the Link layer, is where hosts talk to each other. Protocols here send frames (packets) to other hosts, and receive frames in response
- Layer 3, the Network layer, is used to pass packets between LANs. For example, we often use IP to pass frames between Ethernetconnected hosts

COMPSCI 314 33

Data Link Control (Shay 9.2)

- Link layer is divided in two LLC and MAC
- Shay presents HDLC, a forerunner of IEEE 802.2
- These are bit-oriented protocols




HDLC Frame Format


 Flag pattern, 01111110 (six 1s) marks start and end of frame. Receiver watches medium for flags

number of bits:	8	8 or 16	8 or 16	variable	16 or 32	8
	Flag	Address	Control	Data	FCS	Flag

 How do we send the flag pattern within the data part of the frame?



COMPSCI 314 35



802.2 LLC Header Formats (if used)

DSAP address	SSAP address	Control field	Information field
8 bits	8 bits	8 or 16 bits	N*8 bits

General form of LLC header

- DSAP, SSAP are Service Access Point addresses
 - 04 = IBM SNA, 06 = IP,AA = SNAP (Subnetwork Attachment Point)


								SNAP neader
AA	AA	03	00	00	00	08	00	(8 bytes)
	LC		3 00	ctet C	UI			2-octet type field

- OUI = Organisation Unique Identifier
- Type field values are Ethernet type (Ethertype) values
 - $0800_{16} = \mbox{IP}, \ 0806 = \mbox{ARP}, \ 6003 = \mbox{DECnet phase IV}, \dots$

COMPSCI 314 38

Contention Protocols (Shay 4.7)

- Basic idea: Hosts must share the medium
- Aloha System, 1970s, using packet radio:



Aloha Protocol

- Any host can broadcast a message to Menehune at any time
- If the message is received correctly, Menehune ACKs it (on a different frequency)
- If two host transmissions overlap (and interfere) the message is lost
- If a message is not ACKed the host assumes it was lost, waits a random time, then resends
- Worked and was simple, but not a very efficient use of the medium

COMPSCI 314 39 COMPSCI 314 4(


Carrier Sense Multiple Access (CSMA)

- Like Aloha, listen to medium for any activity
- If no activity, transmit; otherwise wait
- Can still get collisions, various ways to reduce them:
 - use 'slot time,' hosts can only transmit at start of a slot
 - random choice, probability p, to decide whether to transmit or wait for next slot
 - Fig. 4.44 compare various schemes

COMPSCI 314 41

Collision Detection

- · Start transmitting any time, but watch medium for a collision
- · When collision detected, stop transmitting, send jam signal
- This is CSMA/CD



COMPSCI 314 42

How to exit a stop sign using CSMA/CD

